

PROCESSOR CLEANER

PC-600

COMPUTER TO PLATE CHEMISTRY

MAINTENANCE OF PREPRESS EQUIPMENT

CLEANER FOR REMOVAL OF CRYSTALLINE DEPOSITS IN THE CIRCULATION SYSTEMS AND DEVELOPER BATHS OF PLATE PROCESSORS.

PROPERTIES

- ▶ Concentrated acid solution.
- ▶ Eliminates cristaline solid produced by the developer in the baths and circulation systems of plate processors.

APPLICATION

- ▶ Baths and circulation systems of plate processors.

METHOD OF USE

1. Empty the developer bath and tank.
2. Dilute 1 part of **PC-600** to 5 parts of water.
3. Fill the tank and bath with the diluted solution.
4. Set the bath temperature to 30°C to assist in the dissolution of crystals.
5. Leave recirculating for 20 minutes.
6. Empty used product.
7. Fill with clean wter and recirculate for 5 minutes.
8. Empty and refill with developer.

CONSIDERATIONS

- ▶ In case of very incruusted solids, it is recommended to leave the product standing overnight and restart the process from point 4.

PACKAGING

- ▶ 10 litres.